

★★★★  
**Vehicle Value  
 Care+Plus<sup>SM</sup>**

**ENGINE<sup>1</sup>**



Cam housing gasket(s)  
 Cylinder block  
 Cylinder head(s)  
 Cylinder head gasket(s)  
 EGR valve

Engine mounts  
 Exhaust manifold(s)  
 Exhaust manifold gasket(s)  
 Flywheel or flexplate  
 Front crankshaft seal  
 Harmonic balancer  
 Intake manifold  
 Intake manifold gasket(s)  
 Intercooler

Oil pan  
 Oil pan gasket  
 Oil pump

Rear main seal  
 Ring gear  
 Rotor housings and  
 internal parts

Timing chain(s) or belt(s)  
 Timing chain or belt cover  
 Timing chain or belt  
 tensioner(s)

Timing cover gasket  
 Timing gears  
 Turbocharger or  
 supercharger housing(s)  
 and internal parts

Vacuum pump  
 Valve cover(s)  
 Valve cover gasket(s)  
 Wastegate

Water pump

**TRANSMISSION<sup>1</sup>**



Cooler and metal cooler  
 lines  
 Front pump seal(s)  
 Output shaft seal

Pan gasket  
 Shifter seal  
 Slave cylinder and master  
 cylinder of a manual  
 transmission clutch  
 assembly

Speedometer cable seal  
 Torque converter  
 Transaxle case and  
 internal parts

Transfer case and internal  
 parts  
 Transfer case seals  
 Transmission case and  
 internal parts  
 Transmission mounts  
 Vacuum modulator

Track bars  
 Upper control arms  
 Wheel bearing seals  
 Wheel bearings

Transfer case and internal  
 parts  
 Transfer case seals  
 Transmission case and  
 internal parts  
 Transmission mounts  
 Vacuum modulator

**DRIVETRAIN  
 ASSEMBLY<sup>1</sup>**



Axle seal(s) or gasket(s)  
 Axle shafts and bearings  
 Center bearings and drive  
 shaft yokes

Control processor and  
 sensors  
 Differential gasket(s)  
 Drive shaft(s)

Final drive and axle  
 housing(s) and internal  
 parts  
 Four-wheel drive  
 engagement actuator/  
 motor

Pinion seal  
 Solenoids  
 Traction control linkage

Universal and constant  
 velocity joints

Ball joints  
 Coil springs  
 Control arm bushings  
 Control arm shafts  
 Hub bearing seals  
 Hub bearings

Leaf spring bushings  
 Leaf spring shackles  
 Leaf springs  
 Lower control arms  
 Stabilizer bar bushings  
 Stabilizer bar links  
 Stabilizer bars

Steering knuckles and  
 spindles  
 Strut bar bushings  
 Strut bar links  
 Strut bars  
 Struts

Torsion bar mounts  
 Torsion bars  
 Track bar bushings  
 Track bar links

Accumulator  
 Brake pedal  
 Caliper seals  
 Calipers  
 Combination valve  
 Master cylinder  
 Metal brake line fittings  
 Metal brake lines  
 Parking brake assemblies  
 Power booster  
 Wheel cylinders

Accumulator  
 Belt-driven A/C compressor  
 Blower motor  
 Clutch and coil  
 Compressor  
 Compressor gaskets  
 Compressor seals

Condenser  
 Control cables  
 Ducts  
 Evaporator  
 Expansion valve  
 Heater control valve  
 Heater core  
 Idler pulley  
 Idler pulley bearing

Line o-ring  
 Orifice tube  
 Plenum doors  
 Pulley  
 Receiver-dryer  
 Serpentine belt tensioner  
 Serpentine belt tensioner  
 bearing  
 Serpentine belt tensioner  
 pulley

Accelerator pedal  
 Distribution rails  
 Fuel injectors  
 Fuel level sending unit  
 Fuel pressure regulator  
 Fuel pump  
 Fuel tank  
 Injection pump  
 Metal fuel line fittings  
 Metal fuel lines  
 Throttle body  
 Throttle cable  
 Throttle linkage

Alternator  
 Backup light switch  
 Brake light switch  
 Manually operated switches  
 Neutral safety switch  
 Pulley  
 Starter drive  
 Starter motor  
 Starter solenoid  
 Voltage regulator  
 Wiper motors

★★★★  
**Mechanical Advantage  
 Care+Plus<sup>SM</sup>**

**COOLING  
 SYSTEM**



**SUSPENSION**

Air tubes  
 Air suspension bags  
 Compressor  
 Control processor and  
 sensors  
 Electronic suspension/  
 variable suspension struts  
 and motors/actuators  
 Lines and fittings  
 Switches

**AIR  
 CONDITIONING  
 & HEATING**



Center shaft  
 Control processor  
 Control sensors  
 Four-wheel steering pump  
 Gear housing or rack  
 assembly and their internal  
 parts  
 Power cylinder  
 Stepper motor

**STEERING**



Center shaft  
 Control processor  
 Control sensors  
 Four-wheel steering pump  
 Gear housing or rack  
 assembly and their internal  
 parts  
 Power cylinder  
 Stepper motor

**POWERTRAIN  
 ELECTRONICS**



Cooling fan control processor  
 Cooling fan sensors  
 IAC motor  
 Ignition coil  
 Mixture control processor  
 Mixture control sensors  
 Timing control processor  
 Timing control sensors  
 Transmission shift  
 control processor  
 Transmission shift  
 control sensors

**FUEL SYSTEM**



Accelerator pedal  
 Distribution rails  
 Fuel injectors  
 Fuel level sending unit  
 Fuel pressure regulator  
 Fuel pump  
 Fuel tank  
 Injection pump  
 Metal fuel line fittings  
 Metal fuel lines  
 Throttle body  
 Throttle cable  
 Throttle linkage

**ELECTRICAL**



Accelerator pedal  
 Distribution rails  
 Fuel injectors  
 Fuel level sending unit  
 Fuel pressure regulator  
 Fuel pump  
 Fuel tank  
 Injection pump  
 Metal fuel line fittings  
 Metal fuel lines  
 Throttle body  
 Throttle cable  
 Throttle linkage

**ABS BRAKES**



ABS booster/pump  
 ABS control processor  
 ABS master cylinder  
 ABS sensors  
 ABS solenoids

**INTERIOR  
 ELECTRONICS**



Cruise control assembly  
 Digital dash display  
 Electronic climate control  
 head  
 Heads-up display projector  
 and control unit  
 Trip/mileage/engine function  
 computer

**INCLUDES ALL PREVIOUSLY LISTED  
 PARTS FROM VVC+, PLUS:**

**SUSPENSION**

Air tubes  
 Air suspension bags  
 Compressor  
 Control processor and  
 sensors  
 Electronic suspension/  
 variable suspension struts  
 and motors/actuators  
 Lines and fittings  
 Switches

**AIR  
 CONDITIONING  
 & HEATING**

Center shaft  
 Control processor  
 Control sensors  
 Four-wheel steering pump  
 Gear housing or rack  
 assembly and their internal  
 parts  
 Power cylinder  
 Stepper motor

**STEERING**

Center shaft  
 Control processor  
 Control sensors  
 Four-wheel steering pump  
 Gear housing or rack  
 assembly and their internal  
 parts  
 Power cylinder  
 Stepper motor

**POWERTRAIN  
 ELECTRONICS**

Cooling fan control processor  
 Cooling fan sensors  
 IAC motor  
 Ignition coil  
 Mixture control processor  
 Mixture control sensors  
 Timing control processor  
 Timing control sensors  
 Transmission shift  
 control processor  
 Transmission shift  
 control sensors

**FUEL SYSTEM**

Accelerator pedal  
 Distribution rails  
 Fuel injectors  
 Fuel level sending unit  
 Fuel pressure regulator  
 Fuel pump  
 Fuel tank  
 Injection pump  
 Metal fuel line fittings  
 Metal fuel lines  
 Throttle body  
 Throttle cable  
 Throttle linkage

**ELECTRICAL**

Accelerator pedal  
 Distribution rails  
 Fuel injectors  
 Fuel level sending unit  
 Fuel pressure regulator  
 Fuel pump  
 Fuel tank  
 Injection pump  
 Metal fuel line fittings  
 Metal fuel lines  
 Throttle body  
 Throttle cable  
 Throttle linkage

**ABS BRAKES**

ABS booster/pump  
 ABS control processor  
 ABS master cylinder  
 ABS sensors  
 ABS solenoids

**INTERIOR  
 ELECTRONICS**

Cruise control assembly  
 Digital dash display  
 Electronic climate control  
 head  
 Heads-up display projector  
 and control unit  
 Trip/mileage/engine function  
 computer

★★★★★  
**Automotive Essential Care+Plus<sup>SM</sup>**

*Comprehensive coverage for modern vehicles*

**Automotive Essential Care+Plus covers the most important mechanical parts of the vehicle.**

Examples of non-covered parts are listed below. For a full list, please refer to the contract.<sup>2</sup>



**Vehicle Hardware:** door handles, hood and trunk hinges, bumper impact absorbers, headlamp mounting buckets, hood latch, cargo tie downs, glove box lock assembly, manual seat track assembly, and others



**Routine Maintenance Items:** oil, coolant, fluids, refrigerant, brake pads, spark plugs, and others



**Multimedia Interfaces:** audio speakers and wiring, radios, USB outlets, wireless charging pads, and others



**Replaceable Items:** battery and cables, lights and bulbs, tires, filters, hoses and lines, brake drums, brake shoes, brake rotors, exhaust system, catalytic converter, windshield wiper blades/rubber inserts, shock absorbers, and others



**Convenience and Utility Accessories:** bed liner, in-vehicle vacuum cleaner system and components, heated seat elements when integrated in the seat cushion or upholstery, and others



**Cosmetic Items:** carpet, upholstery, paint, bumpers, fenders, and others



**Four-Wheel and Trailering Accessories:** headlight grills, tow hooks, trailer hitch receivers, auxiliary fuel tanks, and others

**INCLUDED WITH ALL COVERAGES**

**Roadside Assistance**



Towing  
 Flat-tire assistance  
 Lock-out assistance  
 Battery assistance

**Expense Reimbursement  
 Benefits**



Rental car  
 Trip Interruption



**in Florida by CNA National Warranty  
 Corporation-Florida, at the address shown  
 on the left, Florida Company # 60098.**

<sup>1</sup> Coverage begins when the manufacturer's extended powertrain warranty expires. <sup>2</sup> This overview is not all-inclusive. See your service contract for a complete list of exclusions. **Purchase of this product is not required. You may purchase or lease a vehicle without this product. This is not a contract.** Coverage provided under the service contract is secondary to any manufacturer's warranty. This product is not insurance. The product being offered is a service contract and is separate and distinct from any product or service warranty which may be provided by the manufacturer, importer, or seller. Please see service contract for obligations, conditions, limitations, exclusions, and state-specific provisions related to your coverage or benefits. Service Contract Providers: Dealers, Continental Service Provider, Inc. (CA License #0E32746); Continental Service Plan, Inc.; or