# Valuable features of your coverage



# **Roadside assistance**

Simply call the toll-free number 24 hours a day, seven days a week for roadside assistance up to \$50 per occurrence or towing up to \$150 per occurrence. Or, you can call your own provider and we will reimburse you up to these dollar limits.



# **Rental car reimbursement**

We reimburse up to \$50 per day with a maximum of \$350 per occurrence for a rental vehicle when a covered mechanical breakdown occurs and the vehicle is deemed inoperable.



# Trip interruption

We reimburse up to \$100 per day with a maximum of \$300 per occurrence for meals and lodging if you are stranded overnight more than 100 miles from home due to a covered mechanical breakdown.



# Manufacturer's warranty deductible reimbursement

We reimburse up to \$100 toward your deductible for repairs covered by your manufacturer's warranty.



# Repair locations across the U.S. and Canada

Your dealership is generally your best option for repair service needs. However, you'll rest easy knowing that your coverage will be honored at thousands of licensed repair facilities throughout the United States and Canada.



# Future contract guaranty

If you still own your vehicle before your coverage expires, you may be able to purchase a new service contract, subject to eligibility.





# 4150 N. Drinkwater Blvd. Suite 400 Scottsdale, AZ 85251 (800) 345-0191

This is not a contract. Coverage provided under the service contract is secondary to any manufacturer's warranty. This product is not insurance. The product being offered is a service contract and is separate and distinct from any product or service warranty which may be provided by the manufacturer, importer, or seller. Please see service contract for obligations, conditions, limitations, exclusions, and state-specific provisions related to your coverage or benefits. Service Contract Providers: Dealers, Continental Service Provider, Inc. (CA License #0E32746); Continental Service Plan, Inc.; or

# in Florida by CNA National Warranty Corporation-Florida, at the address shown above, Florida Company #60098.

©2025 CNA National Warranty Corporation 8858 (06/25)

# AUTOMOTIVE PREFERRED CARE+PLUS<sup>544</sup> VSC



# PREFERRED PROTECTION FOR THE ROAD AHEAD

Peace of mind with the most comprehensive coverage on the road.

# Drive with confidence knowing you're covered

Purchasing a vehicle is a significant investment that is worth protecting. While vehicles today are more advanced than ever before, there is always the chance of a mechanical breakdown that requires a major repair. With Automotive Preferred Care+Plus, you can help reduce or even eliminate the financial burden of repairs.

# The smart choice to help reduce out-of-pocket expenses

Automotive Preferred Care+Plus was developed with top-of-the-line protection, given the increasing age of vehicles on the road and advancements in vehicle technology.



# Automotive **Preferred Care+Plus<sup>SM</sup>** is so comprehensive, it's easier to tell you which parts aren't covered.

Accessory drive belt(s), hoses, radiator cap, tubes (except those tubes expressly covered in your service contract), coolant pipes and clamps

Antenna (including shark fin) mast(s) and mirrors

Audio speakers and wiring

Body, body panels, body fasteners, chassis frame and bumpers

Brake drums, rotors, pads and linings, brake backing plate assembly

Bright metal, trim, upholstery, carpet, insulation and paint

Convertible top

Exhaust system and catalytic converter

Filters and filter housings, adapters

Fuses and fusible links Glass, including fogged or hazy headlight lenses Jack and tool kit, wheel lugs and

lua nuts Manual transmission clutch disc, pressure plate and throw-out

bearing Any parts or components of a natural gas/propane fuel system

PCV valve, oil separator and fuel vapor canister


Spark plugs, plug wires and glow plugs

Starting, lighting, ignition (SLI) battery

Tires, wheels and wheel covers Windshield wiper blades/rubber

# Examples of covered parts »

inserts





Cam housing gasket(s)

Cylinder head gasket(s)

Cylinder block

EGR valve

Cylinder head(s)

Engine mounts

Exhaust manifold(s)

Flywheel or flexplate

Front crankshaft seal

Intake manifold gasket(s)

Timing chain(s) or belt(s)

Timing chain or belt cover

Turbocharger or supercharger

housing(s) and internal parts

...

Timing chain or belt

Timing cover gasket

tensioner(s)

Timing gears

Vacuum pump

Valve cover(s)

Wastegate

Water pump

Valve cover gasket(s)

**TRANSMISSION**<sup>1</sup>

Manual clutch slave and

Speedometer cable seal

Transaxle case and internal

Transfer case and internal parts

Transmission case and internal

Front pump seal(s)

master cylinders

Output shaft seal

Torque converter

Transfer case seals

Transmission mounts

Vacuum modulator

Pan gasket

Shifter seal

parts

parts

Cooler and metal cooler lines

Harmonic balancer

Intake manifold

Intercooler

Oil pan gasket

Rear main seal

Oil pan

Oil pump

Ring gear



4x4 locking hub Axle seal(s) or gasket(s) Axle shafts and bearings Center bearings and drive shaft yokes Control processor and sensors Differential gasket(s) Drive shaft(s) Exhaust manifold gasket(s) Final drive and axle housing(s) and internal parts Four-wheel drive engagement actuator/motor Pinion seal Solenoids Traction control linkage Universal and constant velocity joints

# **SUSPENSION**

Rotor housings and internal parts Air tubes Air suspension bags Ball joints Coil springs Compressor Control arm bushings Control arm shafts Control processor and sensors Electronic suspension/variable suspension struts and shocks Hub bearing seals Hub bearings Leaf spring bushings Leaf spring shackles Leaf springs Lines and fittings Lower control arms Shocks Stabilizer bars Steering knuckles and spindles Strut bar bushings Strut bar links Struts Switches Torsion bar mounts Torsion bars Track bar bushings Track bar links Track bars Upper control arms Wheel bearing seals

Wheel bearings

**STEERING** 



# **ELECTRICAL**

Alternator Backup light switch Brake light switch Manually operated switches Neutral safety switch Pulley and mounting bracket Starter drive Starter motor Starter solenoid Voltage regulator Wiper motors

# FUEL SYSTEM

Accelerator pedal Distribution rails Fuel injectors Fuel level sending unit Fuel pressure regulator Fuel pump Fuel tank Injection pump Metal fuel lines and fittings Throttle body Throttle cable Throttle linkage





ABS booster/pump ABS control processor ABS master cylinder ABS sensors ABS solenoids Accumulator Brake pedal Calipers and seals Combination valve Master cylinder Metal brake line fittings Metal brake lines Parking brake assemblies Power booster

Wheel cylinders

Auxiliary fuel tank



Bed liner except for warpage Bed-mounted fifth-wheel hitch Brush guards Cargo lamp Cargo tie-downs Headlight grills Pop-out or sliding side/rear window latches Power winch moto Power winch rollers Rail protectors Running boards Running light bodies and lenses Skid plates Spare tire carrier Spare tire swing arm Step bumpers and mounting brackets Swing-away mirror arms and mounts Tailgate handle Tailgate hinges Tailgate lock and cables Tow hooks

### OCCUPANT PROTECTION

Trailer hitch receiver

Airbag fault/warning light Airbag module Impact sensor Occupancy sensors Restraints/airbag control module

Ash tray assembly Bumper impact absorbers Courtesy light switches Glove box lock assembly Headlamp mounting buckets Interior/exterior lamp assemblies LED lighting Manual seat track assembly Parking and side lamp bodies and sockets Hood latch and cables Hood hinges and springs Side door handles Side door hinges Trunk hinaes Trunk lid striker plate Trunk torsion bars

### AIR CONDITIONING I $(\bullet)$ & HEATING

A/C compressor clutch A/C compressor coil A/C compressor mounting bracket A/C compressor pulley Accumulator Belt-driven A/C compressor Blower motor Compressor gaskets and seals Condenser Control cables Ducts Evaporator Expansion valve Heater control valve Heater core Idler pulley Idler pulley bearing Idler pulley mounting bracket Line o-rings Metal A/C lines Orifice tube Plenum doors Receiver-drver Serpentine belt tensioner Serpentine belt tensioner bearing Serpentine belt tensioner pulley







Wiring harnesses

### OCCUPANT RESTRAINT



- Seat belt(s)
- Seat belt buckles/latches
- Seat belt buckle switch
- Seat belt buckle retractors/ tensioners
- Seat belt pretensioner
- Seat belt motors
- Seat belt reminder buzzer
- Seat belt reminder lamp





- Electric fan motor Fan
- Fan clutch Fan shroud
- Recovery tank
- Thermostat

### INTERIOR ELECTRONICS



- Adaptive cruise control
- Cruise control assembly
- Digital dash display
- Electronic climate control head Heads-up display projector and control unit
- Navigation system
- Infotainment screens
- Trip/mileage/engine function computer

### POWERTRAIN ELECTRONICS



- Cooling fan control processor
- Cooling fan sensors
- IAC motor
- lanition coil
- Mixture control processor
- Timing control processor
- Timing control sensors
- Transmission shift control processor
- Transmission shift control sensors

## CONVENIENCE ACCESSORIES

Adaptive headlamp system Automatic park assist system Convertible top frame Heated seat elements Heated steering wheel Horn Horn relay Memory seat activator switches Memory seat control processor Memory seat motors Memory seat solenoids Memory seat sensors Near-object avoidance camera(s) Near-object avoidance sensors Power antenna motor Power door lock actuator Power door lock motor Power door lock relavs Power headlamp motor Power mirror motors Power seat motor Power sunroof motor Power tailgate motor Power tailgate solenoids Power top motor Power trunk motor Power trunk solenoids Power window motor Rain-sensing wiper system Rear window defogger Rear window defroster Steering wheel activator switches Steering wheel control processor Steering wheel motors Steering wheel solenoids Steering wheel sensors Window regulator





High voltage supply Hvdraulic tubes Inverter Motor/generator Receptacle